



Powering Business Worldwide

pe.eaton.com

XT Manual Motor Protection Accessories - Electrical Connection Module

XTPAXECMD

Dimensions:

- **Height:** X
- **Length:** X
- **Width:** X

Notes: Main current wiring between XTPR...D and contactor

Warranties: No Data

Specifications:

- **Special Features:** Used with XTPR...D + XTCE...D
- **Type:** Accessory

Supporting documents:

- [Eatons Volume 5-Motor Control and Protection](#)
- [Eaton Specification Sheet - XTPAXECMD](#)
- [Global Data Sheet - XTPAXECMD](#)

Certifications: No Data

Product compliance: No Data

